



1. Sensing Mat
(200x200 mm)



2. Sensing Mat
(1370 x 70 mm)



3. Transportation
bag



4. Foam roll



5. Velcro® straps



6. Electronic
module and USB
cable



7. Pin bars

Install the Sensing Mat

1. **Remove the content** from the transportation bag (element 3).
2. **Remove the Sensing Mats (elements 1, 2) from the plastic bags.**
3. **Place the Sensing Mat** element 1 on a flat surface or the element 2 around a mattress.
4. **Connect the electronic module** (element 6) to one of the mats using the pin bars provided (element 7).
5. **Switch on the electronic unit.** The red LED will start blinking.

Install the Demo Software

Recommended Requirements: Intel Core® i5, Windows® 10, 4 GB RAM, USB, Bluetooth® connectivity. Using a system with lower features can cause a malfunction of the software.

1. **Install the Demo Software as an Administrator to use all the features of the system.** You can find the installation file in the Dropbox folder we provided in an email after your purchase.
2. **Connect the Sensing Mat to your computer.**
 - a. **Via Bluetooth:**
 - i. Go to the Bluetooth settings in your computer or device and pair your electronic unit. The requested password is 1234. The Switch Mat and your computer must be at no more than 5 m to ensure proper connection.
 - ii. Identify the COM assigned to your electronic unit. To do so go to Control Panel > Hardware and Sound > Devices and Printers. Locate the unit, right click and go to "Properties". In the properties window, choose the "Hardware" tab, place the mouse pointer over the first line available and you will see the COM assigned to your electronic unit. The format is COM##, where ## is a number.
 - iii. Run the software and choose your Development Kit in the initial screen of the program.
 - iv. In the software window, select your COM from the drop-down menu at the top-left of the screen and click the "play" icon. Now the Switch Mat is successfully connected to your device and the "play" icon will change to a red "stop" icon.
 - b. **Via USB:**
 - i. Plug the USB connector between the electronic unit and your computer.
 - ii. Run the software and choose your Development Kit in the initial screen of the program.
 - iii. Identify the COM assigned to your electronic unit. To do so go to Control Panel > Hardware and Sound > Devices and Printers. Locate the unit, right click and go to "Properties". In the properties window, choose the "Hardware" tab, place the mouse pointer over the first line available and you will see the COM assigned to your electronic unit. The format is COM##, where ## is a number.
 - iv. In the software window, select your COM from the drop-down menu at the top-left of the screen and click the "play" icon. Now the Mat is successfully connected to your device and the "play" icon will change to a red "stop" icon.



The Switch Mat Development Kit must be only used on flat surfaces and installed as instructed. Only store the product using the original packaging. Not following the installation instructions or altering the Switch Development Kit in any form without prior authorization from Sensing Tex will cause a void warranty.

Please contact our support team at support@sensingtex.com if you have questions or need assistance.