



1. *Mattress cover*



2. *Sensing Mat and Electronic Module*



3. *Protective rubber and Velcro*



4. *Transportation module bag*



5. *Foam tube*



6. *USB cable*

Install the Sensing Mat

1. **Remove the content** from the transportation bag (element 4)
2. **Remove the Velcro straps (element 3)** and unroll the mat (element 1)
3. **Place the Sensing Mat** on a flat surface
4. **Plug the USB Cable on the electronic unit** and 5VDC USB. The red LED will start blinking.

Install the Demo Software

Recommended Requirements: Intel Core® i5, Windows® 10, 4 GB RAM, USB. Using a system with lower features can cause a malfunction of the software.

1. **Install the Demo Software as an Administrator to use all the features of the system.** You can find the installation file in the folder or access we provided in an email after your purchase.
2. **Connect the Sensing Mat to your computer.**

Via USB:

 - i. Plug the USB connector between the electronic unit and your computer.
 - ii. Run the software and choose your Development Kit in the initial screen of the program.
 - iii. Identify the COM assigned to your electronic unit. To do so go to Control Panel > Hardware and Sound > Devices and Printers. Locate the unit, right click and go to "Properties". In the properties window, choose the "Hardware" tab, place the mouse pointer over the first line available and you will see the COM assigned to your electronic unit. The format is COM##, where ## is a number.
 - iv. In the software window, select your COM from the drop-down menu at the top-left of the screen and click the "play" icon. Now the Mat is successfully connected to your device and the "play" icon will change to a red "stop" icon.

 **The Mattress Mat Development Kit must be only used on flat surfaces and installed as instructed. Only store the product using the original packaging. Not following the installation instructions or altering the Development Kit in any form without prior authorization from Sensing Tex will cause a void warranty.**

Please contact our support team at support@sensingtex.com if you have questions or need assistance.